



GIRNAR 1

2 Year Warranty
2 Jahre Garantie
Garantie de 2 ans
2 Años de Garantía
2 Års Garanti

GIRNAR 1



Made in India



Instructions


www.gipfelclimbing.com

Gipfel Climbing Equipment
Maxwel Exporters, Kunda Road
Partapur, Meerut 250103, UP
India

Customer care: cs@gipfelclimbing.com

This tent consists of:


- 1 x Inner tent
and outer rainfly



- 3 x Poles
(1 big and 1 small)




- 13 x Ground Anchors



Step 1

Spread the tent and anchor the 6 ground points to the ground.




Step 2

Insert the poles in the pole sleeves. The poles must be inserted in the respective sleeves as shown in Figure 1 (Step 1).



Step 3

Anchor the guy lines at all 7 points.



Note

If you would like to remove the outer rainfly and only use the inner tent as mosquito net, you can easily disconnect the outer from the inner and pitch the tent like this.

